
## Installing Certificate in host

 Download the D-tacq CA certificate https://www.d-tacq.com/ssl/dtacq\_ca.crt






## Right click then install


















sudo mkdir /usr/local/share/ca-certificates/dtacq
sudo cp dtacq\_ca.crt /usr/local/share/ca-certificates/dtacq
sudo update-ca-certificates

